

## Internal loading valve Ã~100 whittaker f614a



**Product codes:** 

**Product attributes:** 

Reference: PC170-00004 EAN13: -UPC: -

## **Product description:**

The bottom loading valve DN100 WHITTAKER F614A and its level sensor, are designed for refueller vehicles. Model F614A is for loading and unloading, with flow rates up to 800 gpm (3028 L / min). Unloading requires the use of atmospheric pressure to open the internal valve. This valve is typically used with a model F613A level sensor. The bottom load control closes automatically when the tank liquid level has reached the preset level sensor. The valve can be used with one or two tank level sensors.